



Top button Compartment

This will allow you to disassemble the button compartment to take apart the back cover.

Written By: Joseph DoctorPinkney



INTRODUCTION

Using a metal spudger may cause damage but it is the most efficient tool to use. There is a sticky adhesive under the top button compartment followed by a metal piece then a rubber piece. Once you get the first part off the rest is simple.



TOOLS:

- [Phillips #00 Screwdriver](#) (1)
 - [Metal Spudger](#) (1)
-

Step 1 — Top button Compartment



- Insert the flat end of wide metal spudger into the seam of the plastic buffer surrounding the buttons and pry it open.

Step 2



- Use A #00 Phillips head screwdriver and turn counterclockwise to remove the four indicated screws.
- Set the screws aside.

Step 3



- Apply pressure and turn counterclockwise to remove the indicated 2.5 mm screw.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-09-21 09:53:05 AM.